

Directions for use: -

1: Thoroughly clean the area to be inspected with '**THE WORKS**' **CLEAN-ALL**

cleaner/degreaser and wipe dry.

2: Spray '**THE WORKS**' **DYE PENETRANT** onto the area under inspection, ensuring total coverage, and leave for up to 15 minutes to allow the dye to penetrate.

3: Wipe the area with a dry cloth removing the **DYE PENETRANT** from the surface.

4: Clean the area again by wetting a clean dry cloth with **CLEAN-ALL** and wipe the surface down again. Try to wipe in one direction only. Wipe dry.

5: Spray on '**THE WORKS**' **DEVELOPER** which will dry as a white powdery coating.

Allow up to 10 minutes for development. Faults will now be clearly visible.

6: After inspection remove the developer using **CLEAN-ALL**. If necessary any remaining traces of dye can easily be removed by spraying with **CLEAN-ALL** and rinsing off with water.